


MTS-1 SINGLE AXIS POSITIONER

- Program memory 10 steps
- 24Vdc reverse voltage protected
- Isolated 6 inputs
- Isolated 6 mosfet outputs
- Encoder supply 24Vdc
- Indexing working



1	General	4
1.1	Keypad and display	
2	Technical features	7
2.1	Specifications	
2.2	Inputs-Outputs	
3	Running	8
3.1	Modes	
3.2	Manual Movements	
3.3	Assigning value to current position(Calibration)	
4	Recipe	9
4.1	Create a recipe	
5	Parameters	9
5.1	Accessing to parameters	
5.2	Parameters list	
5.2.1	Parameter 1: Axis Calibration	
5.2.2	Parameter 2: Selecting unit	
5.2.3	Parameter 3: Encoder counter direction	
5.2.4	Parameter 4: Encoder resolution	
5.2.5	Parameter 5: Display resolution	
5.2.6	Parameter 6: Axis minimum position	
5.2.7	Parameter 7: Axis maximum position	
5.2.8	Parameter 8: Axis positioning tolerance	
5.2.9	Parameter 9: Axis set value offset	
5.2.10	Parameter 10: Retract distance	
5.2.11	Parameter 11: Retract delay time	
5.2.12	Parameter 12: Switching to slow speed distance	

- 5.2.13 Parameter 13: Direction of exceeding the set point
- 5.2.14 Parameter 14: Distance value to exceed set point
- 5.2.15 Parameter 15: Number of attempts to find the set value
- 5.2.16 Parameter 16: Index position
- 5.2.17 Parameter 17: Index mode enable
- 5.2.18 Parameter 18: Direction switching delay
- 5.2.19 Parameter 19: Complement to set value
- 5.2.20 Parameter 20: Absolute or Relative Selection
- 5.2.21 Parameter 21: 7-segment scanning calibration
- 5.2.22 Parameter 22: Reserved
- 5.2.23 Parameter 23: Device working time
- 5.2.24 Parameter 24: Load the default parameters

6 Error Codes

17


1. General

MTS-1 Single axis position controller. Thanks to mosfet outputs, high performance positioning without analog outputs is possible.

1.1 Keypad and display

	Access to the parameters page. First, password screen is seen. Password is 333'
	Used to access to the recipe page.
	Used to change the second line 7-segment display value.
	Used to confirm the entered value or to start the axis movement
	Used to cancel the entered value or to stop the axis movement
	Used to move the axis back manually
	Used to move the axis forward manually
	Used to move the axis manually at high speed
	Used to calibrate the axis value.
	Used to turn on or off the retract feature.
	Used to run the recipe steps sequentially

	Inpos: Indicates whether the axis is in position. Rel: Relative mod selected  :Indicates whether retract mode is enabled. Retract mode cannot be enabled if the retract value is 0.  :Indicates whether recipe mode is active or not.
---	---

	Line1 : 6 digits. Shows the actual value. gösterir. If x key is pressed when there is no movement it shows the set value. Line 2 : 3 digits. Shows the counter value. If x key is pressed when there is no movement it shows the set value.
---	---

2 Technical features

2.1 Specifications

- Supply: 24Vdc $\pm$ 15% reverse voltage protection
- Digital inputs: 6 isolated
- Digital outputs: 6 isolated 0.7A mosfet
- Encoder supply
- Encoder inputs: A, B
- Panel dimensions: 144x144mm
- 7-Segment display height: 14mm

2.2 Inputs-Outputs

Power		
Earth	Supply	
Gnd		
Not Connected		
Not Connected		
In Position	Outputs	
High Speed		
Reverse		
Forward		
Encoder Power 24Vdc	Encoder Supply	
Encoder Power Gnd		
Encoder B Phase		
Encoder A Phase		
Index	Normally Open	Inputs
Retract	Normally Open	
Quantity	Normally Open	
External Stop	Normally Open	
External Start	Normally Open	
Enabled	Normally Closed	

3 Running

3.1 Modes

Each rising trigger of external start signal or pushing **E** button starts axis positioning.

3.2 Manual Movements

Using **H** **▶** **◀** buttons the axis can be moved manually. Buttons **▶** and **◀** moves the axis at slow speed. By pressing **H** button with **▶** or **◀** button, axis moves at high speed in desired direction.

3.3 Assigning value to current position (Calibration)

First, access to parameters page. To do that push the **P** button. 'PASS' message appears in the first line. Using keypad enter 333 and push the **E** button to access parameters page. The first parameter is CAL meaning calibration. Enter the required value and push the **E** button. So the axis position is updated.

The second way is to use **C** button. Thus, accessing the full of parameters list is restricted. This time password is 444. So the rest of the procedure is the same as already explained above.

If indexing enabled, index position should be changed and restart the device.

4 Recipe

4.1 Create a recipe

Push the **R** button to access recipe page. STEP01 is seen in the first line. To move the next step **R** button is pressed. To access to content, press **E** the button. To load selected step to main screen as it is push the **E** button again. Then LOAD? Message is seen. To confirm press **E** button. If necessary, step's values can be edited using numeric buttons. To save edited position value press **E** button. Then, second line starts to blink. If needed second line can be edited. To save the counter value press **E** again. This time LOAD? Message is seen. To confirm loading the single step press **E** button. To return to main screen without loading the current step push **X** button. To load all the steps push the **M** button when the main screen is on. Steps which counter value's are zero are inactive.

5 Parameters

5.1 Accessing to parameters

Press the **P** button to access the parameters page. In the first line, PASS(password) message is seen. Enter 333 and push the **E** button. If an incorrect value is entered, FAULT message is displayed for a while and then returns to main screen.

Press the **E** button to access the next parameter. Use keypad to edit any parameter. Then press the **E** button to

save it or press **X** the button to cancel. Pressing **X** the button again or waiting 10seconds causes to return to main screen.

5.2 Parameters List

5.2.1 Axis calibration:

Description: Assigns to axis position.

Valid range: 0-999999

Default value: None.

Parameter resolution: Parameter display resolution's value

5.2.2 Selecting unit:

Description: Selects the unit mm or inch.

Valid range: 0:mm 1:inch

Default value:0

Parameter resolution:0

5.2.3 Encoder counter direction:

Description: Defines the counting direction.

Valid range: 0: positive 1:negative

Default value: 0

Parameter resolution:0

5.2.4 Encoder resolution:

Description: Defines the pulses per mm or inch.

Valid range: 0.000-999.999

Default value: 80.000

Parameter resolution:3

5.2.5 Display resolution:

Description: Defines positioning resolution.

Let's say 500mm

500 for resolution 0

500.0 for resolution 1

500.00 for resolution 2

500.000 for resolution 3

Valid range: 0-3

Default value: 1

Parameter resolution:0

5.2.6 Axis minimum position:

Description: Defines the minimum limit of the axis.

Valid range: 0-999999

Default value: 5.0

Parameter resolution: Parameter display resolution's value

5.2.7 Axis maximum position:

Description: Defines the maximum limit of the axis.

Valid range: 0-999999

Default value: 1000.0

Parameter resolution: Parameter display resolution's value

5.2.8 Axis positioning tolerance:

Description: Defines the axis positioning tolerance. As long as the difference between set and actual position is less than tolerance, axis is accepted in position.

Valid range: 0-9999.99

Default value: 0

Parameter resolution: 2 for mm / 3 for inch

5.2.9 Axis set value offset:

Description: Put an offset value to set position.

Example 1

actual pos: 100.0mm
set pos: 200.0mm
offset: 0.1mm
positioning stops at 199.9mm

Example 2

actual pos: 200.0mm
set pos: 100.0mm
offset: 0.1mm
positioning stops at 100.1mm

Valid range: 0-9999.99

Default value: 0.0

Parameter resolution: 2 for mm / 3 for inch

5.2.10 Retract distance:

Description: Defines the retract distance of the axis. If the value is higher than 0mm/inch, using the  button retract function can be enabled or disabled. If the value is zero retract feature is always disabled.

Valid range: 0-9999.99

Default value: 0.00

Parameter resolution: 2 for mm / 3 for inch

5.2.11 Retract delay time:

Description: Delay for retract movement.

Valid range: 0.0-99999.9

Default value: 0.0

Parameter resolution: 1

5.2.12 Switching to slow speed Distance:

Description: Defines the transition point from high speed to low speed. It is defined as the distance from the set point.

Valid range: 0-9999.99

Default value: 10.00

Parameter resolution: 2 for mm / 3 for inch

5.2.13 Direction of exceeding the set point:

Description: “Direction of exceeding the set point”, “Distance to exceed set point” parameters are related. Defines the direction in which the axis approaches the set position.

0: positive

1: negative

Valid range: 0-1

Default value: 0

Parameter resolution: 0

5.2.14 Distance value to exceed set point

Description: Defines how far the axis exceeds the set point before reaching the setpoint.

Valid range: 0-999.999

Default value: 0.000

Parameter resolution: 3

5.2.15 Number of attempts to find the set value:

Description: Defines the number attempts to find the set value. If it is 0, device searches until it finds the set position.

Valid range: 0-9999999

Default value: 0

Parameter resolution: 0

5.2.16 Index position:

Description: Defines the indexing point. Index mode enable parameter should be 1.

Valid range: 0-9999999

Default value: 800.0

Parameter resolution: Parameter display resolution's value

5.2.17 Index mode enable:

Description: Enables or disables the index mode.

1: index mode on

0: index mode off(permanent position memory)

Valid range: 0-1

Default value: 0

Parameter resolution: 0

5.2.18 Direction switching delay

Description: Delay between forward and reverse movement. Unit is second.

Valid range: 0-99999.9

Default value: 0.0

Parameter resolution: 1

5.2.19 Complement to set value:

Description: Set the displayed value to set value if the parameter is 1 (It does not change the current value).

Valid range: 0-1

Default value: 0

Parameter resolution: 0

5.2.20 Absolute or Relative Selection:

Description: Select the positioning as absolute or relative.

0: Absolute

1: Relative

Valid range: 0-1

Default value: 0

Parameter resolution: 0

5.2.21 7-segment scanning calibration:

Description: None

Valid range: 0-999999

Default value: None

Parameter resolution: 0

5.2.22 Reserved

Description: None

Valid range: 0-1

Default value: 0

Parameter resolution: 0

5.2.23 Device working time:

Description: Displays the operating time in hours. It is not a changeable value. It does not change with the loading of default parameters.

Valid range: 0-999999

Default value: None

Parameter resolution: 0

5.2.24 Load the default parameters:

Description: Restores the default values to parameter list after 1. At the end of the installation, it automatically becomes 0.

Valid range: 0-1

Default value: 0

Parameter resolution: 0

6 Error Codes

- Err 1: Axis position is higher than maximum limit.
- Err 2: Axis position is lower than minimum limit.
- Err 3: Set position is higher than maximum limit.
- Err 4: Set position is lower than minimum limit.
- Err 5: Limit values error
- Err 6: Encoder resolution is zero fault
- Err 7: Encoder direction error
- Err 8: Unit selection error
- Err 9: Display resolution error
- Err 10: Reserved
- Err 11: Reserved
- Err 12: Enable signal error